



FLAT PITCHED

(WITH STEEL ARM SUPPORTS)

FITTING GUIDE

House of Canopies Ltd
Unit 86 Marston Moor Business Park
Tockwith
North Yorkshire
YO26 7QF
Telephone: 01423 623 255
Email: info@houseofcanopies.co.uk

IMPORTANT NOTE

Fitting guide is suitable for solid brickwork & 7KN Blockwork
(Any other substrate may need alternative fixings)

FOR TECHNICAL ADVICE CALL
01423 623 255

1: Fixing The Canopy

For Flat canopies with steel arm supports

Positioning & Fixing

Recommended Fixings:

7.5mm x 100mm Concrete Screws
5mm x 50mm Wood Screws
Hinged Screw Caps
Rawlplugs

Required Tools:

Various Drill Bit Sizes
Silicone Sealant



1.1 Remove lead-effect roof from the canopy base.



1.4 Use 100mm concrete fixings to securely attach the canopy base to the wall.



1.2 Hold the canopy base at a desired height over the door, centralise, and level. Mark through steel plate fixing locations in the back of the base.



1.5 Mark and drill evenly through the roof upstand using a 7mm drill bit. Ideally targeting the centers of the bricks and insert the Rawlplugs.



1.3 Remove the base and drill the indicated holes using an 6mm drill bit.



1.6 To prevent water migration, apply clear silicone sealant to the reverse side of the upstand prior to fixing.

2: Fixing The Roof

For Flat canopies with steel arm supports

Positioning & Fixing The Roof



- 1.7** Secure the roof through the drilled holes in the brick, using wall plugs if necessary, and the provided screw caps.



- 1.8** Apply a bead of silicone sealant along the top of the roof upstand. This is essential, as neglecting it can lead to water ingress inside the base.

- 1.9** Clean down canopy if necessary – refer to cleaning and maintenance guide below.

Cleaning & Maintenance

Regular cleaning & maintenance is essential to maintain a canopies gloss and usability for a long period. This should be carried out every 4 – 6 months, however canopies exposed to harsher environments, such as maritime or industrial environments, may need to be cleaned more often.

Cleaning is done with a soft cloth and warm soapy water, this is suitable for light dirt, fingerprints, and any airborne residue.

AVOID any type of abrasive or aggressive cleaning, such as bleach, alcohol, scouring pads, steel wool or wire brushes to clean any part of the canopy.